

# Heritage Omnipanel Installation

**RUNTAL**  
**RADIATORS**

Thank you for purchasing the new Heritage Omnipanel by Runtal. We are proud of our quality workmanship and are certain that you will be thoroughly satisfied with your purchase. We urge you to contact your local Runtal representative if you have comments or questions.

**NOTE:** This sheet is intended to show installation for the Heritage Omnipanel only. Please refer to the Omnipanel Owners Manual for electrical and plumbing assembly, and general care instructions. For permanent installations, electrical connection or hydronic piping should be performed by qualified professionals. Plug in (P & PG) models are intended for quick and easy homeowner installation.

Runtal has made every effort to insure that all of the materials required for mounting your Heritage Omnipanel have been included. Depending on your specific wall construction, you may have parts left over. This mounting system has been designed for one person, but you may find it helpful to have an assistant.

## Heritage Mounting Hardware

- (2) L-Shaped Wall Brackets w/ Plastic Clips
- (6) 1/8" x 2" Toggle Bolts
- (6) 1/4" x 1-1/2" Lag Screws
- (6) Washers
- (1) 3/16" Allen Wrench

## Tools Required

- Screwdriver
- Level
- Pencil
- Tape Measure
- Drill
- 3/8" Spade Bit

### 1. Locate the Wall Brackets

Mark the wall at the finished height of the Heritage (H=62-3/4"), usually 64" to 72" from the floor. Also mark the width of the Heritage (W=21-5/8") and the mid-point.

Measure out 7" to either side of the mid-point, and measure down 2" from each mark. These are the bracket locations, make 2 marks level to each other.

### 2. Attach the Wall Brackets

Take the lefthand (L) wall bracket and hold it up to the lefthand mark, short leg against the wall. Mark the slot and the hole. Take the righthand (R) bracket repeat the procedure. Push the plastic clips onto the wall brackets.

For hollow wall installation, drill two 3/8" holes for each bracket, and install each bracket with two toggles and washers. Tighten the toggles securely after leveling the brackets.

For solid wall installation, simply install each bracket with two lag screws and washers. Tighten the screws securely after leveling the brackets.

### 3. Hang the Omnipanel

Lift the Omnipanel onto the two wall brackets and center it to the midpoint. Make a mark at the bottom hold down bracket position.

Remove the Omnipanel and drill for a toggle or lag screw at the hold down position.

Hang the Omnipanel onto the brackets and secure the lockdown screw.

### 4. Hang the Heritage Frame

Inspect the wooden Heritage Frame for the two top and two bottom nylon adjustment screws. Use the allen wrench to back the screws out to flush with the frame.

Install the Brass Robe Hooks on the top cross panel. Hang the Frame over the Omnipanel carefully, and tighten the bottom adjustment screws fully.

Tighten the top adjustment screws to raise, or loosen them to lower the Heritage Frame. Adjust the frame so that the wooden cross panels are centered in the Omnipanel openings.