

INSTALLATION INSTRUCTIONS

HOT SPRING

Tools and Material Not Supplied

- Pipe dope
- Tape measure
- Screwdriver
- Level

	Hot 60	Hot 180	Hardware Supplied	
A			1	1
B			2	3
C			2	3
D			2	3
			7mm Dia x 70 mm	
E			4	6
F			1	1
G			1	1
H			1	1
I			1	1




fig 1. Bracket Positions

Assembly Instructions

Sufficient quality pipe dope must be applied to valve- tail threads prior to their installation.

Install the valves using the (1 / 2 inch) Allen Wrench

Install Air Vent (A).

Connect the radiator to heating circuit with air vent on the return.

Accurately mark the bracket holes on the wall using a level, to dimensions shown on the SPECIFICATION DATA sheet. Depending on the radiator height, drill two or three pilot

holes. If wall is hollow sheetrock, drill $\frac{5}{16}$ " hole for toggle bolts (H).

Attach brackets (C) to the wall with screws (D) if wall is solid. If hollow wall use the toggle bolts (H).

Position brackets (C) on the wall with screw holes as shown in figure 1 for maximum rigidity before tightening the screws (D).

Hang the radiator onto brackets (C) by inserting the lugs into the brackets.

Tighten Allen Screws (E) with Allen Wrench (F).

